



Safety Turf Patch Kit Mixing and Installation Instructions:

- 1. Cut around the area to be patched with a utility knife removing any loose rubber.**
- 2. Use the included brush to paint the perimeter of the area to be patched with the Binder.**
- 3. Mix the can of Binder with the granules of EPDM rubber. Wear rubber gloves when mixing the rubber.**
- 4. Mix until all the granules are completely coated.**
- 5. Put the coated rubber granules in the area to be patched and trowel smooth, lubricating the trowel with soapy water.**
- 6. Dispose of any materials not used properly.**
- 7. Clean tools with Acetone.**
- 8. Any questions, please call Safety Turf. Tel: 610-666-0967. E-mail: info@safetyturf.com**

Quality Safety Surfacing Since 1989