

Safety Turf's Clear Coat Mixing and Installation Instructions:



1. Before installing this material, the surface needs to be dry and no precipitation in the near future.
2. Blow off the rubber surface with a leaf blower to remove any debris that is on the matting. Clean off any dirt that is not removed by the blower with water and let dry.



3. Mix equal parts of "Part A" and "Part B" together in a 5 gallon plastic bucket. Use a paint mixing paddle to blend the two parts together. Please use rubber gloves when handling the materials.



4. Mix small quantities for trim work before proceeding to paint roller application. Apply with a brush near equipment and areas that are not accessible by paint roller.



5. Use a paint roller with a ½” nap roller pad and coat the rubber surface. Replace roller pad, as necessary, if it becomes clogged.



6. Use the mixed coating material within approximately 15 min., because the material will begin to thicken and become unusable. Discard thickened material, do not attempt to apply or it will turn white or milky in appearance.
7. The mixed coating material will cure out faster at higher temperatures (Above 80 degrees) and high humidity. We recommend mixing smaller quantities (1/2 – 1 Gal. of each Part) together so it can be applied before it becomes unusable.
8. Clean tools with Acetone.
9. Dispose of used materials properly.

Please note that the surface may become slightly slippery when it becomes wet initially after coating. The slipperiness will go away after a period of time of usage.

Any questions, please call Safety Turf, Inc. at Tel: 610-666-0967