

Safety Turf, Inc.

Patch Kit Mixing and Installation Instructions:

1. Cut around the area to be patched with a utility knife removing any loose rubber.
2. Use the included brush to paint the perimeter of the area to be patched with the binder.
3. Wear rubber gloves when mixing the rubber.
Mix the can of Binder with the granules of EPDM rubber.
4. Mix until all the granules are completely coated.
5. Put the coated rubber granules in the area to be patched and trowel smooth, lubricating the trowel with soapy water.
6. Dispose of any materials not used properly.
7. Clean tools with Acetone.

Any Questions, Please call Safety Turf, Inc.

Office#:610-792-0967

E-mail: info@safetyturf.com