



POURED-IN-PLACE  
RESILIENT SURFACE

## Safety Turf, Inc

P.O. Box 908, Royersford, PA 19468

1-800-804-4595

www.safetyturf.com

info@safetyturf.com

## Patch Kit Mixing and Installation Instructions:

1. Cut around the area to be patched with a utility knife removing any loose rubber.
2. Use the included brush to paint the perimeter of the area to be patched with a little of the binder provided in the enclosed metal can.
3. Wear rubber gloves when mixing the rubber. Mix the remaining of the can of Binder with the granules of EPDM or TPV rubber.
4. Mix until all the granules are completely coated.
5. Put the coated rubber granules in the area to be patched and trowel smooth, lubricating the trowel with soapy water.
6. Dispose of any materials not used per local refuse guidelines.
7. Clean tools with Acetone.

Any Questions, Please call Safety Turf, Inc.

Office#: 610-792-0967 or 1-800-804-4595

E-mail: [info@safetyturf.com](mailto:info@safetyturf.com)

### Change History

Date / Revision	Description of Change
3-8-2023 / A	New

Issued By: SJS

ST-Inst-Patch\_Kit

Effective Date: 3/8/2023 Rev. A

Approved By: SJS

Page 1 of 1

**Manufacturer and Installer of Safety Turf Poured-in-Place Rubber Surfacing Systems**